



Figures and illustrations in this User Manual are provided for reference only and may differ from actual product appearance. Product design and specifications may be changed without notice.

Still image warning

Avoid displaying still images (like jpeg picture files) or still image element (like TV programme logo, panorama or 4:3 image format, stock or news bar at screen bottom etc.) on the screen. Constant displaying of still picture can cause ghosting of LED screen, which will affect image quality. To reduce risk of this effect, please follow below recommendations:

- Avoid displaying the same TV channel for long periods.
- Always try to display any image on full screen, use TV set picture format menu for best possible match.
- Reduce brightness and contrast values to minimum required to achieve desired picture quality, exceeded values may speed up the burnout process.
- Frequently use all TV features designed to reduce image retention and screen burnout, refer to proper user manual section for details.


Securing the Installation Space

Keep the required distances between the product and other objects (e.g. walls) to ensure proper ventilation.

Falling to do so may result in fire or a problem with the product due to an increase in the internal temperature of the product.

- When using a stand or wall-mount, use parts provided by Samsung Electronics only.
- If you use parts provided by another manufacturer, it may result in a problem with the product or an injury due to the product falling.
- The appearance may differ depending on the product.
- Be careful when you contact the TV because some parts can be somewhat hot.

Installation with a stand. Installation with a wall-mount.



For India Only

This marking on the product, accessories or literature indicates that the product and its electronic accessories should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.

For more information on safe disposal and recycling visit our website www.samsung.com/in or contact our Helpline numbers - 18002668282, 180030008282.



BN68-05129A-00

- 1 -

Changing the Input Source

Source List

Use to select TV or other external input sources such as DVD / Blu-ray players / cable box / STB satellite receiver connected to the TV.

1. Press the SOURCE button.
2. Select a desired external input source.

■ TV / AV / Component / HDMI

• You can only choose external devices that are connected to the TV.

In the **Source List**, connected inputs will be highlighted.

How to use Edit Name

Edit Name lets you associate a device name to an input source. To access **Edit Name**, press the **TOOLS** button in **Source List**. Name the device connected to the input jacks to make your input source selection easier.

- When connecting a PC to the HDMI IN port with HDMI cable, you should set the TV to **PC** mode under **Edit Name**.
- When connecting a PC to the HDMI IN port with HDMI to DVI cable, you should set the TV to **DVI PC** mode under **Edit Name**.
- When connecting an AV devices to the HDMI IN port with HDMI to DVI cable, you should set the TV to **DVI** mode under **Edit Name**.


Information

You can see detailed information about the selected external device.

- Information only available for the current connected source.

Remote Control

- This remote control has Braille points on the Power, Channel, and Volume buttons and can be used by visually impaired persons.



- 5 -

Important Safety Instructions

Warning! Important Safety Instructions

(Please read the safety instructions below before installing and using the product.)

CAUTION
RISK OF ELECTRIC SHOCK. DO NOT OPEN

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). THERE ARE NO USER SERVICEABLE PARTS INSIDE. REFER ALL SERVICING TO QUALIFIED PERSONNEL.

This symbol indicates that high voltage is present inside. It is dangerous to make any kind of contact with any internal part of this product.

This symbol indicates that important literature concerning operation and maintenance has been included with this product.

- The slots and openings in the cabinet and in the back or bottom are provided for necessary ventilation. To ensure reliable operation of this apparatus, and to protect it from overheating, these slots and openings must never be blocked or covered.
 - Do not cover the slots and openings with a cloth or other materials.
 - Do not block the slots and openings by placing this apparatus on a bed, sofa, rug or other similar surface.
 - Do not place this apparatus in a confined space, such as a bookcase or built-in cabinet, unless proper ventilation is provided.
- Do not place this apparatus near or over a radiator or heat register, or where it is exposed to direct sunlight.
- Do not place a vessel containing water (vases etc.) on this apparatus, as this can result in a risk of fire, or electric shock.
- Do not expose this apparatus to rain or place it near water (near a bathtub, washbowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool etc.). If this apparatus accidentally gets wet, unplug it and contact an authorized dealer immediately.
- Make sure to pull out the power cord from the outlet before cleaning.
- This apparatus uses batteries. In your community, there might be regulations that require you to dispose of these batteries properly to protect the environment. Please contact your local authorities for disposal or recycling information.
- Do not overload wall outlets, extension cords, or adapters beyond their capacity, since this can result in fire or electric shock.
- Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them. Pay particular attention to the plug end, where connected to adapters, and at the point where they exit from the apparatus.
- To protect this apparatus from a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the set due to lightning and power line surges.
- Before connecting the AC power cord to the DC adaptor cord, make sure the voltage designation of the DC adaptor corresponds to the local electrical supply. (depending on the model)
- Never insert anything metallic into the open parts of this apparatus. Doing so may create a danger of electric shock.
- To avoid electric shock, never touch the inside of this apparatus. Only a qualified technician should open this apparatus.
- Make sure to plug the power cord in until it is firmly inserted. Pull on the plug, not the cord, when removing the power cord from the outlet. Do not touch the power cord with wet hands.
- If this apparatus does not operate normally - in particular, if there are any unusual sounds or smells coming from it - unplug it immediately and contact an authorized dealer or service center.
- Be sure to pull the power plug out of the outlet if the TV is to remain unused or if you are to leave the house for an extended period of time (especially when children, elderly or disabled people will be left alone in the house).
 - Accumulated dust can cause an electric shock, an electric leakage, or a fire by causing the power cord to generate sparks and heat, or cause the insulation to deteriorate.
- Be sure to contact an authorized service center, when installing your set in a location with heavy dust, high or low temperatures, high humidity, chemical substances or where it will operate for 24 hours a day such as in an airport, a train station, etc. Failure to do so may cause serious damage to your set.
- Use only a properly grounded plug and receptacle.
 - An improper ground may cause electric shock or equipment damage. (Class I Equipment only.)
- To turn off the apparatus completely, you must pull the power plug out of the wall socket. Consequently, the power plug should be readily accessible at all times.
- Do not allow children to hang onto the product.
- Store the accessories, batteries, etc. in a location safely out of the reach of children.
- Do not install the product in an unstable location such as a shaky shelf, a slanted floor, or a location exposed to vibration.
- Do not drop or impart a shock to the product. If the product is damaged, disconnect the power cord and contact a service center.
- To clean the product, unplug the power cord from the power outlet and wipe the product using a soft, dry cloth. Do not use any chemicals such as wax, benzene, alcohol, thinners, insecticide, air freshener, lubricant or detergent. This may damage the appearance or erase the printing on the product.
- Do not expose the apparatus to dripping or splashing.
- Do not dispose of batteries in a fire.
- Do not short circuit, disassemble, or overheat the batteries.
- Do not short circuit, disassemble, or overheat the batteries.
- There is a danger of explosion if you replace the batteries with the wrong type of battery. Replace only with the same or equivalent type.
- WARNING - TO PREVENT THE SPREAD OF FIRE, KEEP CANDLES OR OTHER OPEN FLAMES AWAY FROM THIS PRODUCT AT ALL TIMES.


- 2 -

Display Modes (HDMI/DVI Input)

Optimal resolution :1920 x 1080p@60Hz

Mode	Resolution	Horizontal Frequency (kHz)	Vertical Frequency (Hz)	Pixel Clock Frequency (MHz)	Sync Polarity H/V
ISD	720 x 500	31.469	50.000	25.522	+/+
MAC	640 x 480	35.000	60.000	30.240	-/-
	800 x 600	40.725	74.551	37.268	-/-
	680 x 480	31.469	60.000	25.522	-/-
	640 x 480	33.861	72.809	31.500	-/-
	640 x 480	33.500	75.000	31.500	-/-
	800 x 600	37.879	60.317	40.000	+/+
	800 x 600	48.077	72.188	50.000	+/+
	800 x 600	48.875	75.000	48.500	+/+
	1024 x 768	48.363	60.004	65.000	-/-
	1024 x 768	54.428	75.000	75.000	-/-
	1024 x 768	60.023	75.029	76.750	+/+
	1280 x 720	45.000	60.000	74.250	+/+
	1280 x 768	47.712	59.750	66.500	+/+

Installing batteries (Battery size: AAA)



NOTE

- Use the remote control within 23 feet from TV.
- Bright light may affect the performance of the remote control. Avoid using nearby special fluorescent light or neon signs.
- The Colour and shape may vary depending on the model.

Channel List Option Menu **TOOLS**

Set each channel using the **Channel List** menu options [**Add / Delete**, **Add to Favourite / Delete from Favourite**, **Timer Viewing**, **Lock / Unlock**, **Edit Channel Name**, **Sort**, **Select All / Deselect All**, **Auto Store**]. Option menu items may differ depending on the channel status. Set each channel using the **Channel List** menu options. Option menu items may differ depending on the channel status.

Channel Menu

Seeing Channels

Select a channel in the **All Channels**, **Added Channels**, **Favourites** or **Programmed** screen by pressing the **▲ / ▼** buttons, and pressing the **ENTER** button. Then you can watch the selected channel.

- **All Channels:** Shows all currently available channels.
- **Added Channels:** Shows all added channels.
- **Favourites:** Shows all favourite channels.
- **Programmed:** Shows all currently reserved Programmes.

Use the remote control buttons with the **Channel List**.

• **Green (Zoom):** Enlarges or shrinks a channel number.

• **Yellow (Select):** Selects multiple channel lists. Select desired channels and press the Yellow button to set all the selected channels at the same time. The **✓** mark appears to the left of the selected channels.

• **Tools:** Displays the **Channel List** option menu. (The Options menu may differ depending on the situation.)

Channel Status Display icons

Icons	Operations
✓	A channel selected.
✓	A channel set as a favourites.
🔒	A locked channel.
🔄	A reserved programme.

Retuning Channels

Area

You can change the desired area.

Auto Store

(depending on the country)

Scans for a channel automatically and stores in the TV.

- Automatically allocated programme numbers may not correspond to actual or desired programme numbers. If a channel is locked, the PIN input window appears.

Manual Store

Scans for a channel manually and stores in the TV.

- If a channel is locked, the PIN input window appears.
- According to channel source, **Manual Store** may be supported.
- **Programme, Colour System, Sound System, Channel Search, Store:** If there is abnormal sound or no sound, reselect the sound standard required.

- **Channel mode**
 - **P (Programme):** When tuning is complete, the broadcasting stations in your area have been assigned to position numbers from P0 to P99. You can select a channel by entering the position number in this mode.
 - **C (aerial channel mode) / S (cable channel mode):** These two modes allow you to select a channel by entering the assigned number for each aerial broadcasting station or cable channel.

Set each channel using the **Channel List** menu options [**Add / Delete**, **Add to Favourite / Delete from Favourite**, **Timer Viewing**, **Lock / Unlock**, **Edit Channel Name**, **Sort**, **Select All / Deselect All**, **Auto Store**]. Option menu items may differ depending on the channel status. Set each channel using the **Channel List** menu options. Option menu items may differ depending on the channel status.

Channel List Option Menu **TOOLS**

Set each channel using the **Channel List** menu options [**Add / Delete**, **Add to Favourite / Delete from Favourite**, **Timer Viewing**, **Lock / Unlock**, **Edit Channel Name**, **Sort**, **Select All / Deselect All**, **Auto Store**]. Option menu items may differ depending on the channel status.

• **Added / Delete:** Delete or add a channel to display the channels you want.

• **All deleted channels** will be shown on the **All Channels** menu.

• The **Add** menu only appears for deleted channels.

• Delete a channel from the **Added Channels** or **Favourites** menu in the same manner.

• **Add to Favourite / Delete from Favourite **TOOLS****: Set channels you watch frequently as favourites

• **Timer Viewing:** You can set a desired channel to be displayed automatically at the set time, even when you are watching another channel. Set the current time first to use this function.

• **Edit Channel Name:** Assign your own channel name.

• **Sort:** This operation allows you to change the programme numbers of the stored channels. This operation may be necessary after using the auto store.

• **Lock / Unlock:** Lock a channel so that the channel cannot be selected and viewed.

• This function is available only when the **Channel Lock** is set to **On**.

• The PIN input screen appears. Enter your 4-digit PIN, the default of which is "0-0-0-0". Change the PIN using the **Change PIN** option.

• **Select All / Deselect All:** You can select or deselect all channels in the channel list.

• **Auto Store:** Scans for a channel automatically and stores in the TV.

Getting Started


Accessories

- Remote Control & Batteries (AAA x 2)
- Owner's Instructions
- Warranty Card / Regulatory Guide (Not available in some locations)
- Power Cord

Input Cables (Sold Separately)

- Composite (AV)
- Component
- Coaxial (RF)
- HDMI
- HDMI-DVI

TV Controller (Panel Key)



To close the **Menu**, **Media Play List**, or **Source List**, press the Controller for more than 1 second.

When selecting the function by moving the controller to the up/down/left/right directions, be sure not to press the controller. If you press it first, you cannot operate it to move the up/down/left/right directions.

Plug & Play (Initial Setup)

When you turn the TV on for the first time, a sequence of screens and on-screen prompts will assist you in configuring the TV's basic settings. Plug the power cord into a wall outlet, and then press the **POWER** button to turn on the TV. Set the initial setup following instructions that the TV guides.

If you are not using a cable box or satellite box, make you sure have connected the TV to an Aerial or cable connection before you turn on the TV.

Connecting the power cord and antenna. (refer to 'Connections')

Channel Mode

Channels will be switched within the favourite or memorised channel list.

- **Added Channels:** Shows all added channels.
- **Favourite Ch.:** Shows all favourite channels.

Only available in **Standard** mode.

Fine Tune

If the reception is clear, you do not have to fine tune the channel, as this is done automatically during the search and store operation. If the signal is weak or distorted, fine tune the channel manually.

4:3: Sets the picture to basic (4:3) mode.

16:9: Sets the picture to 16:9 wide mode.

Wide Zoom: Magnifies the picture size more than 4:3.

Adjusts the **Position** by using **▲, ▼** buttons.

Zoom: Magnifies the 16:9 wide pictures vertically to fit the screen size.

4:3: Sets the picture to basic (4:3) mode.

Do not watch in 4:3 format for a long time. Traces of borders displayed on the left, right and centre of the screen may cause image retention (screen burn) which are not covered by the warranty.

Screen Fit: Displays the full image without any cut-off when HDMI (720p / 1080i / 1080p) or Component (1080i / 1080p) signals are inputted.

NOTE

After selecting Screen Fit in HDMI (1080i / 1080p) or Component (1080i / 1080p) mode: Adjusts the **Position** or **Size** by using **▲, ▼, ◀, ▶** button.

Depending on the input source, the picture size options may vary.

The available items may differ depending on the selected mode.

Settings can be adjusted and stored for each external device connected to an input on the TV.

If you use the **Screen Fit** function with HDMI 720p input, 1 line will be cut at the top, bottom, left and right in the overscan function.

Contrast, Brightness and Sharpness

Settings can be adjusted and stored for each external device connected to the TV.

Lowering picture brightness reduces power consumption.

Advanced Settings

(available in **Standard / Movie** mode)

Compared to previous models, new Samsung TVs have a more precise picture.

Dynamic Contrast: Adjusts the screen contrast.

Black Tone: Select the black level to adjust the screen depth.

Flesh Tone: Emphasize pink 'Flesh Tone'.

Colour Space: Adjusts the range of colours available to create the image.

White Balance: Adjust the colour temperature for a more natural picture.


R-Offset / G-Offset / B-Offset: Adjust each colour's (red, green, blue) darkness.

R-Gain / G-Gain / B-Gain: Adjust each colour's (red, green, blue) brightness.

Reset: Resets the **White Balance** to its default settings.

Connections

- For better picture and audio quality, connect to a digital device using an HDMI cable.
- The picture may not display normally if at all or the audio may not work if an external device that uses an older version of HDMI mode is connected to the TV. If such a problem occurs, ask the manufacturer of the external device about the HDMI version and, if out of date, request an upgrade.
- Be sure to purchase a certified HDMI cable. Otherwise, the picture may not display or a connection error may occur.
- PC/DVI AUDIO IN input is not supported.
- For HDMI/DVI cable connection, you must use the HDMI IN port.
- Connecting through the HDMI cable may not be supported depending on the PC.
- If an HDMI to DVI cable is connected to the HDMI IN port, the audio does not work.
- For Set-top box connection using HDMI cable, we highly recommend you to connect the HDMI IN port.



The rear panel may differ depending on the model.

Power Input

Component connection

AV connection

Cable

VCR

Blu-ray player / DVD

VHF/UHF Antenna

Sound Menu

Mode **TOOLS**

Standard: Selects the normal sound mode.

Music: Emphasizes music over voices.

Movie: Provides the best sound for movies.

Clear Voice: Emphasizes voices over other sounds.

Amplify: Increase the intensity of high-frequency sound to allow a better listening experience for the hearing impaired.

Equalizer

(standard sound mode only)

Balance: Adjusts the balance between the right and left speaker.

100Hz / 300Hz / 1kHz / 3kHz / 10kHz (Bandwidth Adjustment): Adjusts the level of specific bandwidth frequencies.

Reset: Resets the Equalizer to its default settings.

DTS TruSurround **TOOLS**

(standard sound mode only)

This function provides a virtual 5.1 channel surround sound experience through a pair of speakers using HRTF (Head Related Transfer Function) technology.

Auto Volume

Because each broadcasting station has its own signal conditions, the volume may fluctuate each time channel is changed. This feature lets you automatically adjust the volume of the desired channel by lowering the sound output when the modulation signal is high or by raising the sound output when the modulation signal is low.

Sound Reset

Reset All: Reset all sound settings to the factory defaults.

When you set to **Dual I-II**, the current sound mode is displayed on the screen.

Selecting the Sound Mode **TOOLS**

	Audio Type	Dual I-II	Default
A2 Stereo	Mono	Mono	Automatic change
	Stereo	Stereo ↔ Mono	Automatic change
	Dual	Dual I ↔ Dual II	Dual I
	Dual	Mono	Automatic change
NICAM Stereo	Stereo	Mono ↔ Stereo	Automatic change
	Dual	Mono ↔ Dual I ↔ Dual II	Dual I

If the stereo signal is weak and an automatic switching, occurs, then switch to the mono.

Only activated in stereo sound signal.

This function is available for all input sources.

Setup Menu

Language

Set the menu language.

Select Language and press the **ENTER** button.

Time

The current time will appear every time you press the **INFO** button.

Clock Set: Set the **Day**, **Month**, **Year**, **Hour**, **Minute**.

Sleep Timer **TOOLS**

<

Security

- The PIN input screen appears before the setup screen.
- Enter your 4-digit PIN, the default of which is "0-0-0-0". Change the PIN using the **Change PIN** option.
- Channel Lock:** Lock channels in **Channel List**, to prevent unauthorized users, such as children, from watching unsuitable programme.
- Only available when the input source is set to TV.
- Change PIN:** Change your password required to set up the TV.
- If you forget the PIN code, press the remote control buttons in the following sequence in Standby mode, which resets the PIN to "0-0-0-0": MUTE → 8 → 2 → 4 → POWER (on).

Eco Solution

- Energy Saving (ECOSENSE):** This adjusts the brightness of the TV in order to reduce power consumption. If you select **Picture Off**, the screen is turned off, but the sound remains on. Press any button except volume button to turn on the screen.
- No Signal Power Off:** To avoid unnecessary energy consumption, set how long you want the TV to remain on if it's not receiving a signal.
- Disabled when the PC is in power saving mode.
- Auto Power Off:** The TV will be automatically turned off when no user operation is received for 4 hours.

Auto Protection Time

- Auto Protection Time:** If the screen remains idle with a still image for a certain period of time defined by the user, the screen saver is activated to prevent the formation of ghost images on the screen.

General

- Game Mode:** When connecting to a game console such as PlayStation™ or Xbox™, you can enjoy a more realistic gaming experience by selecting the game mode.
- Precautions and limitations for game mode
 - When no sound is output from the TV because the MUTE button has been pressed.
 - When no sound is output from the TV because the volume has been reduced to minimum with the VOL - button.
 - When the TV is turned off by **Sleep Timer** function.
- After connecting the game console, set **Game Mode to On** to prevent poor picture quality. Unfortunately, you may notice reduced picture quality.
- Melody:** Set so that a melody plays when the TV is turned **Off, Low, Medium and High**.
- The **Melody** does not play.

Application Menu

Enjoy the Media Play

- Using photos, music and/or movie files saved on a USB Mass Storage Class (MSC) device.
- Videos** is not supported in UF4002 model.

Connecting a USB Device

- Turn on your TV.
- Connect a USB device containing photo, music and/or movie files to the USB jack on the side of the TV.
- When USB is connected to the TV, you can select **Media Play**.

Using the Media Play Menu

- Press the MENU button. Press the ▲ or ▼ button to select **Application**, then press the ENTER [↵] button.
- Press the ▲ or ▼ button to select **Media Play (USB)**, then press the ENTER [↵] button.
- Press the ◀ or ▶ button to select an icon (**Videos, Music, Photos, Settings**), then press the ENTER [↵] button.
- It might not work properly with unlicensed multimedia files.
- If you want to view detailed information of the file or connected device, press **TOOLS** button in the file list, and then select **Detailed Information** or **Device Information**.
- Need-to-Know List before using **Media Play (USB)**
 - Supported file systems are FAT and NTFS.
 - Certain types of USB Digital camera and audio devices may not be compatible with this TV.
 - Media Play** only supports USB Mass Storage Class (MSC) devices. MSC is a Mass Storage Class Bulk-Only Transport device. Examples of MSC are Thumb drives and Flash Card Readers. Devices should be connected directly to the TV's USB port. USB HDD is not supported.
 - Before connecting your device to the TV, please back up your files to prevent them from damage or loss of data. SAMSUNG is not responsible for any data file damage or data loss.
 - A USB device that requires high power (more than 500mA or 5V) may not be supported.
 - Do not disconnect the USB device while it is loading.
 - The higher the resolution of the image, the longer it takes to display on the screen.

- The maximum supported JPEG resolution is 15360 x 8640 pixels.
- If a file is corrupted or the TV does not support the file type, the "Not Supported File Format" message appears.
- If a USB extension cable is used, the USB device may not be recognized or the files on the device may not be read.
- The TV cannot play MP3 files with DRM that have been downloaded from a for-pay site. Digital Rights Management (DRM) is a technology that supports the creation, distribution, and management of digital content in an integrated and comprehensive way, including protecting the rights and interests of content providers, preventing illegal copying of contents, and managing billings and settlements.
- PTP device is not supported.
- If an over-power warning message is displayed while you are connecting or using a USB device, the device may not be recognized or may malfunction.
- If the TV has no input during the time set in **Auto Protection Time**, the Screensaver will run.
- The power-saving mode of some external hard disk drives may be released automatically when you connect them to the TV.
- If a USB device connected to the TV is not recognized, the list of files on the device is corrupted, or a file in the list is not played, connect the USB device to a PC, format the device, and check the connection.
- If a file you deleted from the PC is still found when you run **Media Play** use the "Empty the Recycle Bin" function on the PC to permanently delete the file.
- Photos** only supports sequential jpeg format.
- The scene search and thumbnail functions are not supported in the **Videos**.
- If the number of files and folders saved on a USB storage device is approximately over 4000, the files and folders may not appear and some folders may not be opened.
- The maximum displayed number of files, including sub folders, in one folder of USB storage device is 2000.
- The media may not be playing smoothly when using the device lower than USB 2.0.
- The file name only works in supported menu language. The other language is not displayed properly.

- Videos (For UF4003)**
 - Press the ◀ or ▶ button to select **Videos**, then press the ENTER [↵] button in the **Media Play** menu.
 - Press the ◀▶/▲/▼ buttons to select the desired video in the file list.
 - Press the ENTER [↵] button or [⏮] (Play) button.
 - The selected file is displayed on the top with its playing time.
 - If video time information is unknown, playing time and the progress bar are not displayed.
 - During video playback, you can search using the ◀ and ▶ button.
 - You can use [REW] and [FF] (FF) buttons during playback.
- In this mode, you can play movie clips contained in a game, but you cannot play the game itself.
- Supported Subtitle Formats
 - External

Name	File extension
MPEG-4 Timed text	.txt
SA-MI	.smi
Subrip	.srt
SubViewer	.sub
Micro DVD	.sub or .txt
SubStation Alpha	.ssa
Advanced SubStation Alpha	.ass

Name	Container	Format
Sub	Asf	Picture Format
SubStation Alpha	MKV	Text Format
Advanced SubStation Alpha	MKV	Text Format
Subrip	MKV	Text Format
MPEG-4 Timed text	MP4	Text Format

- Internal

Supported Video Formats

Extension	Container	Video Codec	Resolution	Frame rate	Bit rate(Mbps)	Audio Codec
*.mp4	MP4	Dxv3.114x5.116.0 H264 AAC	1000x1080 1000x1080 1000x1080	6-30 6-30 6-30	30Mbps 30Mbps 30Mbps	MP3 / AAC
*.avi *.mvi	AVI MVI	Dxv3.114x5.116.0 MPEG2 MPEG4 SP / ASP	1000x1080 1000x1080 1000x1080	6-30 6-30 6-30	30Mbps 30Mbps 30Mbps	MP3 / AC3 / LPCM / ADPCM / DTS Core
*.asf *.wmv	ASF	MPEG4 SP / ASP H264	1000x1080 1000x1080	6-30 6-30	30Mbps 30Mbps	MP3 / AC3 / LPCM / ADPCM / AAC
*.ts	TS	MPEG2	1000x1080	6-30	30Mbps	AC3 / AAC / MP3 / DTS / HE-AAC
*.m2ts		H.264 BP / MP / HP	1000x1080	6-30	30Mbps	
*.m2ts		MPEG1	1000x1080	24/25/30	30Mbps	AC3 / MPEG / LPCM / AAC
*.m2ts	PS	MPEG2	1000x1080	24/25/30	30Mbps	
*.m2ts		H.264 BP / MP / HP	1000x1080	6-30	30Mbps	
*.mpg *.vob	SCGP	MPEG4 SP / ASP	1000x1080	6-30	30Mbps	MP3
*.avi	Avi	H264 H264 Sorenson H.263	1000x1080 1000x1080 1000x1080	6-30 6-30 6-30	30Mbps 30Mbps 30Mbps	MP3

Other Restrictions

- Video content will not play, or not play again, if there is an error in the content or the container.
- Sound or video may not work if the contents have a standard bit rate/ frame rate above the compatible Frame/Sec listed in the table above.
- If the Index Table is in error, the Seek (Jump) function is not supported.
- The menu may take longer to appear if the video's bit rate exceeds 10Mbps.
- Video content can not be played, if there are many contents in one file.
- Videos** is not supported in UF4002 model.

Video Decoder
Supports up to H.264, Level 4.1 H.264 FMO / ASO / RS, VC1 SP / MP / AP L4 and AVCHD are not supported. MPEG4 SP: ASP
- Below 1280 x 720: 60 frame max - Above 1280 x 720: 30 frame max H.263 is not supported. GMC is not supported.

- Music**
 - Press the ◀ or ▶ button to select **Music**, then press the ENTER [↵] button in the **Media Play** menu.
 - Press the ◀▶/▲/▼ buttons to select the desired Music in the file list.
 - Press the ENTER [↵] button or [⏮] (Play) button.
 - During music playback, you can search using the ◀ and ▶ button.
 - [REW] and [FF] (FF) buttons do not function during play.
- Only displays the files with MP3 file extension. Other file extensions are not displayed, even if they are saved on the same USB device.
- If the sound is abnormal when playing MP3 files, adjust the **Equalizer** in the **Sound** menu. (An over-modulated MP3 file may cause a sound problem.)

Photos

- Press the ◀ or ▶ button to select **Photos**, then press the ENTER [↵] button in the **Media Play** menu.
- Press the ◀▶/▲/▼ buttons to select the desired photo in the file list.
- Press the ENTER [↵] button or [⏮] (Play) button.
- NOTE**
 - While a photo list is displayed, press the [⏮] (Play) / ENTER [↵] button on the remote control to start the slide show.
 - All files in the file list section will be displayed in the slide show.
 - During the slide show, files are displayed in order.
 - During the slide show, you can adjust the slide show speed using [◀] (REW) or [▶] (FF) button.
 - You can move to other file using ◀ or ▶ button.
 - Music files can be automatically played during the Slide Show if the **Background Music** is set to **On**.
 - The **Mode in Background Music** cannot be changed until the BGM has finished loading.
- Supported Photo Formats

Image	Photo Base line	Resolution
JPEG	Progressive	15360 x 8704 1024 x 768

Other Restrictions

- CMYK, YCKC Colour space JPEG are not supported.
- Playing Multiple Files**

Playing selected video/music/photo files

 - Press the Yellow button in the file list to select the desired file.
 - Repeat the above operation to select multiple files.
- NOTE**
 - The ✓ mark appears to the left of the selected files.
 - To cancel a selection, press the Yellow button again.
 - To deselect all selected files, press the **TOOLS** button and select **Deselect All**.
- Press the **TOOLS** button, and then select **Play Selected Contents**.
- Playing the video/music/photo file group**

While a file list is displayed, move to any file in desired group.
- Media Play - Additional Functions**

Videos/Music/Photos Play Operation menus

When playing a file, press the **TOOLS** button.

Category	Operation	Videos	Music	Photos
Title	You can move the other file directly.			
Repeat Mode	You can play move and music files repeatedly.	✓	✓	
Picture Size	You can adjust the picture size to your preference.	✓		
Picture Mode	You can adjust the picture setting.	✓		✓
Sound Mode	You can adjust the sound setting.	✓	✓	✓
Subtitle Setting	You can play the video with Subtitles. This function only works if the subtitles are the same file name as the video.	✓		
Audio Format	You can select the digital audio output format.	✓		
Audio Language	You can change the audio language if the video has more than one language.	✓		
Stop Slide Show / Start Slide Show	You can start or stop a Slide Show.			✓
Slide Show Speed	You can select the slide show speed during the slide show.			✓
Background Music	You can set and select background music when watching a Slide Show.		✓	
Zoom	You can zoom into images in full screen mode.			✓
Rotate	You can rotate images in full screen mode.			✓
Information	You can see detailed information about the played file.	✓	✓	✓

Settings

- Using the Setup Menu**
 - DixX® Video On Demand:** Shows the registration code authorized for the TV. If you connect to the DixX web site and register with 10-digit registration code, you can download the VOD activation file. Once you play it using **Media Play**, the registration is completed.
 - For more information on DixX® VOD, visit http://vod.dixx.com.
- Information:** Select to view information on the connected device.

Using the Sports Mode

Sports Mode [TOOLS]

- This mode provides optimised condition for watching sports games.
- When **Sports Mode is On**, the picture and sound modes are set to **Stadium** automatically.
- If you turn the TV off while watching **Sports Mode**, the **Sports Mode** will be disabled.

Support Menu

Self Diagnosis

- Picture Test:** Use to check for picture problems. If the problem continues to occur, check the colour pattern.
- Sound Test:** Use the built-in melody sound to check for sound problems.
- Reset:** Reset all settings to the factory defaults.
- The PIN input screen appears before the setup screen.
- Enter your 4-digit PIN. Change the PIN using the **Change PIN** option.

Software Upgrade

- Software Upgrade** can be performed by downloading the latest firmware from "www.samsung.com" to a USB memory device.

HD Connection Guide

Refer to this information when connecting external devices to the TV.

Contact Samsung

View this information when your TV does not work properly or when you want to upgrade the software. You can find information regarding our call centres, and how to download products and software.

Other Information

Installing the Wall Mount

- The wall mount kit (sold separately) allows you to mount the TV on the wall. For detailed information on installing the wall mount, see the instructions provided with the wall mount. Contact a technician for assistance when installing the wall mount bracket.
- Samsung Electronics is not responsible for any damage to the product or injury to yourself or others if you elect to install the TV on your own.

Wall Mount Kit Specifications (VESA)

- The wall mount kit is not supplied, but sold separately.
- Install your wall mount on a solid wall perpendicular to the floor. When attaching to other building materials, please contact your nearest dealer.
- If you install the TV on a ceiling or slanted wall, it may fall and result in severe personal injury.


- NOTE**
 - Standard dimensions for wall mount kits are shown in the table below.
 - When purchasing our wall mount kit, a detailed installation manual and all parts necessary for assembly are provided.
 - Do not use screws that do not comply with the VESA standard screw specifications.
 - Do not use screws longer than the standard dimension, as they may cause damage to the inside of the TV set.
 - For wall mounts that do not comply with the VESA standard screw specifications, the length of the screws may differ depending on the wall mount specifications.
 - Do not fasten the screws too firmly. This may damage the product or cause the product to fall, leading to personal injury. Samsung is not liable for these kinds of accidents.
 - Samsung is not liable for product damage or personal injury when a non-VESA or non-specified wall mount is used or the consumer fails to follow the product installation instructions.
 - Do not mount the TV at more than a 15 degree tilt.
 - Always have two people mount the TV on a wall.

Product Family	Models	VESA screw hole spaces (A * B) in millimeters	Standard	Quantity
LED-TV	UA23F4002 / UA23F4003	75 X 75	M4	4

Do not install your Wall Mount Kit while your TV is turned on. It may result in personal injury due to electric shock.

Securing the TV to the Wall

- Caution: Pulling, pushing, or climbing onto the TV may cause the TV to fall. In particular, ensure that your children do not hang over or destabilize the TV, doing so may cause the TV to tip over, resulting in serious injuries or death. Follow all safety precautions provided on the included Safety Flyer. For added stability, install the anti-fall device for safety purposes, as follows.



Troubleshooting

If you have any questions about the TV, first refer to this list. If none of these troubleshooting tips apply, please visit "www.samsung.com," then click on Support, or contact the call centre listed on the back-cover of this manual.

Problem	Possible Solution
Picture Quality	
The TV image does not look as good as it did in the store.	<ul style="list-style-type: none">If you have an analogue cable/set top box, upgrade to a digital set top box. Use HDMI or Component cables to deliver HD (high definition) picture quality.Cable/Satellite subscribers: Try HD stations from the channel line up.Antenna connection: Try HD stations after performing Auto tuning.Many HD channels are up scaled from SD(Standard Definition) contents.Adjust the Cable/Set top box video output resolution to 1080i or 720p.Make sure you are watching the TV at the minimum recommended distance based on the size and definition of the signal.
The picture is distorted: macroblock error, small block, dots, pixelization	<ul style="list-style-type: none">Compression of video contents may cause picture distortion especially in fast moving pictures such as sports and action scenes.Low signal level or bad quality can cause picture distortion. This is not a TV issue.Mobile phones used close to the TV (cca up to 1m) may cause noise in picture on analogue and digital TV.
Colour is wrong or missing.	<ul style="list-style-type: none">If you're using a component connection, make sure the component cables are connected to the correct jacks. Incorrect or loose connections may cause colour problems or a blank screen.
There is poor colour or brightness.	<ul style="list-style-type: none">Adjust the Picture options in the TV menu. (go to Picture mode / Colour / Brightness / Sharpness)Adjust Energy Saving option in the TV menu. (go to MENU - Setup - Eco Solution - Energy Saving)Try resetting the picture to view the default picture settings. (go to MENU - Picture - Picture Reset)
There is a dotted line on the edge of the screen.	<ul style="list-style-type: none">If the picture size is set to Screen Fit, change it to 16:9.Change cable/satellite box resolution.
The picture is black and white.	<ul style="list-style-type: none">If you are using an AV composite input, connect the video cable (yellow) to the Green jack of component input 1 on the TV.
When changing channels, the picture freezes or is distorted or delayed.	<ul style="list-style-type: none">If connected with a cable box, please try to reset the cable box. Reconnect the AC cord and wait until the cable box reboots. It may take up to 20 minutes.Set the output resolution of the cable box to 1080i or 720p.
Sound Quality	
There is no sound or the sound is too low at maximum volume.	<ul style="list-style-type: none">Please check the volume of the external device connected to your TV.
The picture is good but there is no sound.	<ul style="list-style-type: none">Set the Speaker Select option to TV Speaker in the sound menu.If you are using an external device, make sure the audio cables are connected to the correct audio input jacks on the TV.If you are using an external device, check the device's audio output option (ex. you may need to change your cable box's audio option to HDMI when you have a HDMI connected to your TV).If you are using a HDMI cable, a separate audio cable is required.If your TV has a headphone jack, make sure there is nothing plugged into it.
The speakers are making an inappropriate noise.	<ul style="list-style-type: none">Check the cable connections. Make sure a video cable is not connected to an audio input.For antenna or cable connections, check the signal strength. Low signal level may cause sound distortion.
No Picture, No Video	
The TV will not turn on.	<ul style="list-style-type: none">Make sure the AC power cord is securely plugged in to the wall outlet and the TV.Make sure the wall outlet is working.Try pressing the POWER button on the TV to make sure the problem is not the remote. If the TV turns on, refer to "The remote control does not work" below.
The TV turns off automatically.	<ul style="list-style-type: none">Ensure the Sleep Timer is set to Off in the Time menu.Make sure the AC power cord is plugged in securely to the wall outlet and the TV.When watching TV from an antenna or cable connection, the TV will turn off after 10 - 15 minutes if there is no signal.
There is no picture/video.	<ul style="list-style-type: none">Check cable connections (remove and reconnect all cables connected to the TV and external devices).Set your external devices' (Cable/Set top Box, DVD, Blu-ray etc) video outputs to match the connections to the TV input. For example, if an external device's output is HDMI, it should be connected to an HDMI input on the TV.Make sure your connected devices are powered on.Be sure to select the TV's correct source by pressing the SOURCE button on the TV remote.

Problem	Possible Solution
RF(Cable/Antenna) Connection	
The TV is not receiving all channels.	<ul style="list-style-type: none">Make sure the Antenna cable is connected securely.Please try Setup (initial setup) to add available channels to the channel list. Go to MENU - System - Setup (initial setup) and wait for all available channels to be stored.Verify the Antenna is positioned correctly.
The picture is distorted: macroblock error, small block, dots, pixelization	<ul style="list-style-type: none">Compression of video contents may cause picture distortion, especially on fast moving pictures such as sports and action scenes.A low signal can cause picture distortion. This is not a TV issue.
PC Connection	
A "Mode Not Supported" message appears.	<ul style="list-style-type: none">Set your PC's output resolution so it matches the resolutions supported by the TV.
The video is OK but there is no audio.	<ul style="list-style-type: none">If you are using a HDMI connection, check the audio output setting on your PC.
Others	
The picture will not display in full screen.	<ul style="list-style-type: none">HD channels will have black bars on either side of the screen when displaying up scaled SD (4:3) contents.Black bars on the top and bottom will appear during movies that have aspect ratios different from your TV.Adjust the picture size options on your external device or TV to full screen.
The remote control does not work.	<ul style="list-style-type: none">Replace the remote control batteries with the poles (+/-) in the right direction.Clean the transmission window located on the top of the remote control.Try pointing the remote directly at the TV from 5-6 feet away.
The cable/set top box remote control does not turn the TV on or off, or adjust the volume.	<ul style="list-style-type: none">Programme the Cable/Set top box remote control to operate the TV. Refer to the Cable/Set top box user manual for the SAMSUNG TV code.
A "Mode Not Supported" message appears.	<ul style="list-style-type: none">Check the supported resolution of the TV, and adjust the external device's output resolution accordingly. Refer to resolution settings in this manual.
There is a plastic smell from the TV.	<ul style="list-style-type: none">This smell is normal and will dissipate over time.
TV is tilted to the right or left side.	<ul style="list-style-type: none">Remove the stand base from the TV and reassemble it.
There are difficulties assembling the stand base.	<ul style="list-style-type: none">Make sure the TV is placed on a flat surface. It is necessary to use magnetized screw driver if you cannot remove the screws from the TV.
The Broadcasting menu is grey out (unavailable).	<ul style="list-style-type: none">The Broadcasting menu is only available when the TV source is selected.
Your settings are lost after 30 minutes or every time the TV is turned off.	<ul style="list-style-type: none">If the TV is in the Store Demo mode, it will reset audio and picture settings every 30 minutes. If you want to change the settings from Store Demo mode to Home Use, press the SOURCE button to select TV mode, and go to MENU → Support → Update → Update.
You have intermittent loss of audio or video.	<ul style="list-style-type: none">Check the cable connections and reconnect them.Loss of audio or video can be caused by using overly rigid or thick cables. Make sure the cables are flexible enough for long term use. If mounting the TV to the wall, we recommend using cables with 90 degree connectors.
You see small particles when you look closely at the edge of the frame of the TV.	<ul style="list-style-type: none">This is part of the product's design and is not a defect.
There are recurrent picture/sound issues.	<ul style="list-style-type: none">Check and change the signal/source.
A reaction may occur between the rubber cushion pads on the base stand and the top finish of some furniture.	<ul style="list-style-type: none">To prevent this, use felt pads on any surface of the TV that comes in direct contact with furniture.

- This TFT LED panel uses a panel consisting of sub pixels which require sophisticated technology to produce. However, there may be a few bright or dark pixels on the screen. These pixels will have no impact on the performance of the product.
- You can keep your TV as optimum condition to upgrade the latest firmware on web site (samsung.com → Support → Downloads) by USB.

Storage and Maintenance

- If you remove the attached sticker on the TV screen, clean the residues and then watch TV.

	Do not spray water directly onto the product. Any liquid that goes into the product may cause a failure, fire, or electric shock.
	Clean the product with a soft cloth dampened with in a small amount of water. Do not use a flammable liquid (e.g. benzene, thinners) or a cleaning agent.

License	
DixX Certified® to play DixX® video up to HD 1080p, including premium content.	
ABOUT DIXX VIDEO: DixX® is a digital video format created by DixX, LLC, a subsidiary of Rowi Corporation. This is an official DixX Certified® device that plays DixX video. Visit dixx.com for more information and software tools to convert your files into DixX videos. ABOUT DIXX VIDEO-ON-DEMAND: This DixX Certified® device must be registered in order to play purchased DixX Video-on-Demand (VOD) movies. To obtain your registration code, locate the DixX VOD section in your device setup menu. Go to vod.dixx.com for more information on how to complete your registration. Covered by one or more of the following U.S. patents : 7,295,673; 7,460,668; 7,515,710; 7,519,274 DixX®, DixX Certified® and associated logos are trademarks of Rowi Corporation or its subsidiaries and are used under license.	
Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.	
Manufactured under a license from U.S. Patent Nos: 5,956,674, 5,974,380, 5,978,762, 6,487,535, 6,226,616, 7,212,872, 7,003,467, 7,272,567, 7,668,723, 7,292,185, 7,890,194, 7,333,959 and 7,646,853. DTS, the Symbol, and DTS and the Symbol together are registered trademarks & DTS Premium Sound is a trademark of DTS, Inc. ©2012 DTS, Inc. All Rights Reserved.	
Manufactured under a license from U.S. Patent Nos: 6,285,767, 8,027,477, 5,319,713, 5,333,201, 5,638,452, 5,771,295, 5,970,152, 5,912,976, 7,200,236, 7,492,907, 8,050,434, 7,720,240, 7,031,474, 7,907,736 and 7,764,802. DTS, the Symbol, and DTS and the Symbol together are registered trademarks & DTS Studio Sound is a trademark of DTS, Inc. ©2012 DTS, Inc. All Rights Reserved.	
HDMI	The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.
Open Source License Notice	In the case of using open source software, Open Source Licenses are available on the product menu. Open Source License Notice is written only English.