











Punch Kit Installation Guide



SL-HPU501F
SL-HPU501S
SL-HPU501T





10




11




12



13



14



15

