

## F/W Upgrade Method by USB flash drive

### How to prepare F/W Update file via USB flash drive

1. Download the newest firmware file onto your computer from [www.samsung.com](http://www.samsung.com).
2. If the firmware file is compressed (\*.zip), the file should be uncompressed
3. Connect a USB flash drive to your computer.
4. If there are previous versions of firmware in the folder on USB flash drive, delete them.
5. Copy the new folder to USB flash drive.

### Warning

The following events may interrupt the upgrade process and

**MAY RESULT IN PERMANENT DAMAGE TO THE UNIT.**

1. Unplugging the power cord.
2. Power Outage.

### How to upgrade the BD Player

1. Insert the USB flash drive into the BD Player while it is ON.
2. In the product's menu, go to Settings > Support > Software Update.
3. Select Update now.

The product searches for the software on the USB drive.

When it finds the software, the Update Request pop-up appears.

4. Select OK. The product upgrades the software, turns off, and then turns on automatically.