


S/W Upgrade Method by USB Flash Drive

※ NOTE :

If the speaker is connected to the Internet, press the Mute () button on the top of the speaker for more than 5 seconds. It will automatically update S/W.

And when the software update is complete, the speaker will automatically reboot.

Preparation :

1. Visit www.samsung.com
2. Download the latest USB software upgrade zip archive to the computer.
3. Unzip the zip archive to the computer.
You should have a single folder with the same name as the zip file.
4. Copy the folder to a USB flash drive.


Warning :


The following events may interrupt the upgrade process and MAY RESULT IN PERMANENT DAMAGE TO THE UNIT.

1. Unplugging the power cord
2. Power Outage.

How to Upgrade the WAM Speaker by USB :

1. Power on the WAM Speaker
2. Insert the USB flash drive into the SERVICE port of the speaker.



3. And then reboot the speaker. It will automatically download new S/W from USB.
Or you can reboot the speaker by pressing Internet Radio Preset () button.

