



## Duct Type Series

Slim duct : AM\*\*\*\*NLD\*\*\*

AM022/028/036\*NMD\*\*\*

MA duct : AM\*\*\*\*NMD\*\*\*

HSP duct : AM\*\*\*\*NHD\*\*\*

# Air Conditioner user manual

imagine the possibilities

Thank you for purchasing this Samsung product.



EN TR RU UK KK IN FR AR DB68-03871A-08

**SAMSUNG**

# Features of your new air conditioner

---

## Cool Summer Offer

On those hot sweltering summer days and long restless nights, there is no better escape from the heat than the cool comforts of home. Your new air conditioner brings an end to exhausting hot summer days and lets you rest. This summer, beat the heat with your own air conditioner.

## Cost Efficient System

Your new air conditioner not only provides maximum cooling power in the summer, but can also be an efficient heating method in the winter with the advanced "Heat pump" system.

This technology is up to 300% more efficient than electrical heating, so you can further reduce its running cost. Now, meet year-round needs with one air conditioner.

## Flexible installation

Duct type air conditioner is designed to be slimmer and offers different solutions for any shape room allowing for specific air flow requirements. Also, the air intake can be set up on either the bottom or rear of the unit, so there is more flexibility in installation.

# Contents

Safety precautions .....	4
Viewing your air conditioner .....	12
Using your air conditioner .....	13
Cleaning and maintaining the air conditioner .....	15
Appendix.....	19
Instruction for packing and unpacking the unit .....	24
Technical Specifications .....	24



## ***Correct Disposal of This Product (Waste Electrical & Electronic Equipment)***

### ***(Applicable in countries with separate collection systems)***

This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling.








Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

# Safety precautions

Before using your new air conditioner, please read this manual thoroughly to ensure that you know how to safely and efficiently operate the extensive features and functions of your new appliance.


Because the following operating instructions cover various models, the characteristics of your air conditioner may differ slightly from those described in this manual. If you have any questions, call your nearest contact center or find help and information online at [www.samsung.com](http://www.samsung.com).

## Important safety symbols and precautions:

 <b>WARNING</b>	Hazards or unsafe practices that may result in <b>severe personal injury or death</b> .
 <b>CAUTION</b>	Hazards or unsafe practices that may result in <b>minor personal injury or property damage</b> .
	Follow directions.
	Do NOT attempt.
	Make sure the machine is grounded to prevent electric shock.
	Unplug the power plug from the wall socket.
	Do NOT disassemble.

## FOR INSTALLATION

### **WARNING**

 **Use the power line with the power specifications of the product or higher and use the power line for this appliance only. In addition, do not use an extension line.**

- ▶ Extending the power line may result in electric shock or fire.
- ▶ Do not use an electric transformer. It may result in electric shock or fire.
- ▶ If the voltage/frequency/rated current condition is different, it may cause fire.

**The installation of this appliance must be performed by a qualified technician or service company.**

- ▶ Failing to do so may result in electric shock, fire, explosion, problems with the product, or injury.

**❗ Install a switch and circuit breaker dedicated to the air conditioner.**

- ▶ Failing to do so may result in electric shock or fire.

**Fix the outdoor unit firmly so that the electric part of the outdoor unit is not exposed.**

- ▶ Failing to do so may result in electric shock or fire.

**⊘ Do not install this appliance near a heater, inflammable material. Do not install this appliance in a humid, oily or dusty location, in a location exposed to direct sunlight and water (rain drops). Do not install this appliance in a location where gas may leak.**

- ▶ This may result in electric shock or fire.

**Never install the outdoor unit in a location such as on a high external wall where it could fall.**

- ▶ If the outdoor unit falls, it may result in injury, death or property damage.

**⚡ This appliance must be properly grounded. Do not ground the appliance to a gas pipe, plastic water pipe, or telephone line.**

- ▶ Failure to do so may result in electric shock, fire, an explosion, or other problems with the product.
- ▶ Never plug the power cord into a socket that is not grounded correctly and make sure that it is in accordance with local and national codes.

# Safety precautions

---

## FOR INSTALLATION



CAUTION

**❗ Install your appliance on a level and hard floor that can support its weight.**

- ▶ Failing to do so may result in abnormal vibrations, noise, or problems with the product.

**Install the draining hose properly so that water is drained correctly.**

- ▶ Failing to do so may result in water overflowing and property damage.

**When installing the outdoor unit, make sure to connect the draining hose so that draining is performed correctly.**

- ▶ The water generated during the heating operation by the outdoor unit may overflow and result in property damage.  
In particular, in winter, if a block of ice falls, it may result in injury, death or property damage.

## FOR POWER SUPPLY



WARNING

**❗ When the circuit breaker is damaged, contact your nearest service center.**

**⊘ Do not pull or excessively bend the power line. Do not twist or tie the power line. Do not hook the power line over a metal object, place a heavy object on the power line, insert the power line between objects, or push the power line into the space behind the appliance.**

- ▶ This may result in electric shock or fire.

## FOR POWER SUPPLY



CAUTION

**⚡ When not using the air conditioner for a long period of time or during a thunder/lightning storm, cut the power at the circuit breaker.**

- ▶ Failing to do so may result in electric shock or fire.

**Install the indoor unit (receiver) in a place far away from the lighting equipment of the ballast.**

**❗ If the appliance is flooded, please contact your nearest service center.**

▶ Failing to do so may result in electric shock or fire.

**If the appliance generates a strange noise, a burning smell or smoke, unplug the power plug immediately and contact your nearest service center.**

▶ Failing to do so may result in electric shock or fire.

**In the event of a gas leak (such as propane gas, LP gas, etc.), ventilate immediately without touching the power line.**

**Do not touch the appliance or power line.**

▶ Do not use a ventilating fan.

▶ A spark may result in an explosion or fire.

**To reinstall the air conditioner, please contact your nearest service center.**

▶ Failing to do so may result in problems with the product, water leakage, electric shock, or fire.

▶ A delivery service for the product is not provided. If you reinstall the product in another location, additional construction expenses and an installation fee will be charged.

▶ Especially, when you wish to install the product in an unusual location such as in an industrial area or near the seaside where it is exposed to the salt in the air, please contact your nearest service center.

**⊘ Do not touch the circuit breaker with wet hands.**

▶ This may result in electric shock.

**Do not strike or pull the air conditioner with excessive force.**

▶ This may result in fire, injury, or problems with the product.

**Do not place an object near the outdoor unit that allows children to climb onto the machine.**

▶ This may result in children seriously injuring themselves.

# Safety precautions

## FOR USING



### WARNING

⊘ **Do not turn the air conditioner off with the circuit breaker while it is operating.**

- ▶ Turning the air conditioner off and then on again with the circuit breaker may cause a spark and result in electric shock or fire.

**After unpacking the air conditioner, keep all packaging materials well out of the reach of children, as packaging materials can be dangerous to children.**

- ▶ If a child places a bag over its head, it may result in suffocation.

**Do not insert your fingers or foreign substances into the air inlet/outlet of the air conditioner.**

- ▶ Take special care that children do not injure themselves by inserting their fingers into the product.

**Do not use this air conditioner for long periods of time in badly ventilated locations or near infirm people.**

- ▶ Since this may be dangerous due to a lack of oxygen, open a window at least once an hour.

⊘ **If any foreign substance such as water has entered the appliance, cut the power by unplugging the power plug and turning the circuit breaker off and then contact your nearest service center.**

- ▶ Failing to do so may result in electric shock or fire.

⊘ **Do not attempt to repair, disassemble, or modify the appliance yourself.**

- ▶ Do not use any fuse (such as cooper, steel wire, etc.) other than the standard fuse.
- ▶ Failing to do so may result in electric shock, fire, problems with the product, or injury.



**❗ Do not place objects or devices under the indoor unit.**

- ▶ Water dripping from the indoor unit may result in fire or property damage.

**Check that the installation frame of the outdoor unit is not broken at least once a year.**

- ▶ Failing to do so may result in injury, death or property damage.

**Max current is measured according to IEC standard for safety and current is measured according to ISO standard for energy efficiency.**

**⊘ Do not stand on top of the appliance or place objects (such as laundry, lighted candles, lighted cigarettes, dishes, chemicals, metal objects, etc.) on the appliance.**

- ▶ This may result in electric shock, fire, problems with the product, or injury.

**Do not operate the appliance with wet hands.**

- ▶ This may result in electric shock.

**Do not spray volatile material such as insecticide onto the surface of the appliance.**

- ▶ As well as being harmful to humans, it may also result in electric shock, fire or problems with the product.

**Do not drink the water from the air conditioner.**

- ▶ The water may be harmful to humans.

# Safety precautions

---

## FOR USING



- ⊘ **Do not apply a strong impact to the remote controller and do not disassemble the remote controller.**

**Do not touch the pipes connected with the product.**

► This may result in burns or injury.

**Do not use this air conditioner to preserve precision equipment, food, animals, plants or cosmetics, or for any other unusual purposes.**

► This may result in property damage.

**Avoid directly exposing humans, animals or plants from the air flow from the air conditioner for long periods of time.**

► This may result in harm to humans, animals or plants.

**This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.**

## FOR CLEANING



### WARNING

- ⊘ **Do not clean the appliance by spraying water directly onto it. Do not use benzene, thinner or alcohol to clean the appliance.**

▶ This may result in discoloration, deformation, damage, electric shock or fire.

**Before cleaning or performing maintenance, unplug the air conditioner from the wall socket and wait until the fan stops.**

▶ Failing to do so may result in electric shock or fire.

## FOR CLEANING



### CAUTION

- ⓘ **Take care when cleaning the surface of the heat exchanger of the outdoor unit since it has sharp edges.**

▶ To avoid cutting your fingers, wear thick cotton gloves when cleaning it.

- ⊘ **Do not clean the inside of the air conditioner by yourself.**

▶ For cleaning inside the appliance, contact your nearest service center.

▶ When cleaning the internal filter, refer to the descriptions in the 'Cleaning and maintaining the air conditioner' section.


▶ Failure to do so may result in damage, electric shock or fire.

# Viewing your air conditioner


Congratulations on the purchase of the air conditioner. We hope you enjoy the features of your air conditioner and stay cool or warm with optimal efficiency.

Please read the user manual to get started and to make the best use of the air conditioner.


## Slim duct type



## MA duct type



## HSP duct type




Your air conditioner may look slightly different from the illustration shown above depending on your model.

# Using your air conditioner

## Tips on using air conditioner

Here are some tips that you would follow when using your air conditioner.

TOPIC	RECOMMENDATION
Cooling	<ul style="list-style-type: none"><li>• If current outside temperatures are much higher than the selected indoor temperature, it may take time to bring the inner temperature to the desired coolness.</li><li>• Avoid drastically turning down the temperature. Energy is wasted and the room does not cool faster.</li></ul>
Heating	<ul style="list-style-type: none"><li>• Since the air conditioner heats the room by taking heat energy from outdoor air, the heating capacity may decrease when outdoor temperatures are extremely low. If you feel the air conditioner insufficiently heats, using an additional heating appliance in combination with the air conditioner is recommended.</li></ul>
Frost & De-ice	<ul style="list-style-type: none"><li>• When the air conditioner runs in Heat mode, due to temperature difference between the unit and the outside air, frost will form. If this happens:<ul style="list-style-type: none"><li>- The air conditioner stops heating.</li><li>- The air conditioner will operate automatically in De-ice mode for 10 minutes.</li><li>- The steam produced on the outdoor unit in De-ice mode is safe.</li></ul></li><li>• No intervention is required; after about 10 minutes, the air conditioner operates again normally.</li></ul> <div> NOTE The unit will not operate when it starts to de-ice.</div>
Fan	<ul style="list-style-type: none"><li>• Fan may not operate for about 3~5 minutes at the beginning to prevent any cold blasts while the air conditioner is warming up.</li></ul>

# Using your air conditioner

TOPIC	RECOMMENDATION
High indoor/ outdoor temperatures	<ul style="list-style-type: none"><li>• If both indoor and outdoor temperatures are high and the air conditioner is running in Heat mode, the outdoor unit's fan and compressor may stop at times. This is normal; wait until the air conditioner turns on again.</li></ul>
Power failure	<ul style="list-style-type: none"><li>• If a power failure occurs during the operation of the air conditioner, the operating immediately stops and unit will be off. When power returns, the air conditioner will run automatically.</li></ul>
Protection mechanism	<ul style="list-style-type: none"><li>• If the air conditioner has just been turned on after operation stops or being plugged in, cool/warm air does not come out for 3 minutes to protect the compressor of the outdoor unit.</li></ul>

# Cleaning and maintaining the air conditioner


For the best performance from your air conditioner, clean it periodically. When cleaning, make sure to unplug from the unit for user's safety.

## Cleaning the filter


When cleaning the filter, make sure to unplug the power from the unit. Washable foam based Air filter captures large particles from the air. The filter is cleaned with a vacuum or by hand washing.

### Slim duct type

1. Slide out the Air filter on the rear side panel to the right side.




2. Clean the Air filter with a vacuum cleaner or soft brush. If dust is too heavy, then rinse it with running water and dry it in a ventilated area.



#### NOTE

- For best conditions, repeat every two weeks.
- If the Air filter dries in a confined (or humid) area, odors may generate. If it occurs, re-clean and dry it in a ventilated area.

3. Insert the Air filter back in its original position.




#### NOTE

- The illustration shown above may differ from your depending on your model.
- After cleaning the filter, press the Filter Reset button on the remote control for 2 seconds to reset the filter schedule. Filter sign indicator will be on for cleaning time.


# Cleaning and maintaining the air conditioner

## MA/HSP duct type

1. Slide out the Air filter on the rear side panel to the right side.




2. Clean the Air filter with a vacuum cleaner or soft brush. If dust is too heavy, then rinse it with running water and dry it in a ventilated area.



NOTE

- For best conditions, repeat every two weeks.
- If the Air filter dries in a confined (or humid) area, odors may generate. If it occurs, re-clean and dry it in a ventilated area.

3. Insert the Air filter back in its original position.



NOTE

- The illustration shown above may differ from your depending on your model.
- After cleaning the filter, press the Filter Reset button on the remote control for 2 seconds to reset the filter schedule. Filter sign indicator will be on for cleaning time.



## MAINTAINING YOUR AIR CONDITIONER

If the air conditioner will not be used for an extended period of time, dry the air conditioner to maintain it in best condition.

1. Dry the air conditioner thoroughly by operating in Fan mode for 3 to 4 hours and disconnect the power plug. There may be internal damage if moisture is left in components.
2. Before using the air conditioner again, dry the inner components of the air conditioner again by running in Fan mode for 3 to 4 hours. This helps remove odors which may have generated from dampness.

### Periodical checks

Refer to the following chart to maintain the air conditioner properly.

Type	Description	Monthly	Every 4 months	Once a year
Indoor unit	Clean the air filter (1)	●		
	Clean the condensate drain pan (2)			●
	Thoroughly clean the heat exchanger (2)			●
	Clean the condensate drain pipe (2)		●	
	Replace the remote control batteries (1)			●
Outdoor unit	Clean the heat exchanger on the outside of the unit (2)		●	
	Clean the heat exchanger on the inside of the unit (2)			●
	Clean the electric components with jets of air (2)			●
	Verify that all the electric components are firmly tightened (2)			●
	Clean the fan (2)			●
	Verify that all the fan assembly is firmly tightened (2)			●
	Clean the condensate drain pan (2)			●



#### NOTE

The checks and maintenance operations described are essential to guarantee the efficiency of the air conditioner. The frequency of these operations varies according to the characteristics of the area, the amount of dust, etc.

- The described operations should be performed more frequently if the area of installation is very dusty.



#### CAUTION

These operations must always be performed by qualified personnel. For more detailed information, see the Installation Manual.

# Cleaning and maintaining the air conditioner

## Internal protections via the unit control system

This internal protection operates if an internal fault occurs in the air conditioner.

Type	Description
Against cold air	The internal fan will be off to against cold air when the heat pump is heating.
De-ice cycle	The internal fan will be off to against cold air when the heat pump is heating.
Anti-protection of internal battery	The compressor will be off to protect internal battery when the air conditioner operates in Cool mode.
Protect compressor	The air conditioner does not start operating immediately to protect the compressor of the outdoor unit after it has been started.



NOTE

If the heat pump is operating in Heat mode, De-ice cycle is actuated to remove frost from an outdoor unit that may have deposited at low temperatures.  
The internal fan is switched off automatically and restarted only after the de-ice cycle is completed.

# Appendix

## Troubleshooting

Refer to the following chart if the air conditioner operates abnormally. This may save time and unnecessary expenses.

PROBLEM	SOLUTION
The air conditioner does not operate immediately after it has been restarted.	<ul style="list-style-type: none"><li>Because of the protective mechanism, the appliance does not start operating immediately to keep the unit from overloading. The air conditioner will start in 3 minutes.</li></ul>
The air conditioner does not work at all.	<ul style="list-style-type: none"><li>Check that the power plug is properly connected. Insert the power plug into the wall socket correctly.</li><li>Check if the circuit breaker is switched off.</li><li>Check if there is a power failure.</li><li>Check your fuse. Make sure it is not blown out.</li></ul>
The temperature does not change.	<ul style="list-style-type: none"><li>Check if you selected Fan mode. Press the <b>Mode</b> button on the remote control to select another mode.</li></ul>
The cool (warm) air does not come out of the air conditioner.	<ul style="list-style-type: none"><li>Check if the set temperature is higher (lower) than the current temperature. Press the <b>Temperature</b> button on the remote control to change the set temperature. Press the <b>Temperature</b> button to decrease or increase the temperature.</li><li>Check if the air filter is blocked by dirt. Clean the air filter every two weeks.</li></ul>

## Appendix

PROBLEM	SOLUTION
The cool (warm) air does not come out of the air conditioner.	<ul style="list-style-type: none"><li>• Check if the air conditioner has just been turned on. If so, wait 3 minutes. Cool air does not come out to protect the compressor of the outdoor unit.</li><li>• Check if the air conditioner is installed in a place with a direct exposure to sunlight. Hang curtains on windows to boost cooling efficiency.</li><li>• Check if the cover or any obstacle is not near the outdoor unit.</li><li>• Check if the refrigerant pipe is too long.</li><li>• Check if the air conditioner is only available in Cool mode.</li><li>• Check if the remote control is only available for cooling model.</li></ul>
The fan speed does not change.	<ul style="list-style-type: none"><li>• Check if you selected Auto or Dry mode. The air conditioner automatically adjusts the fan speed to Auto in Auto/Dry mode.</li></ul>
Timer function does not set.	<ul style="list-style-type: none"><li>• Check if you press the <b>Power</b> button on the remote control after you have set the time.</li></ul>

PROBLEM	SOLUTION
Odors permeate in the room during operation.	<ul style="list-style-type: none"> <li>• Check if the appliance is running in a smoky area or if there is a smell entering from outside. Operate the air conditioner in Fan mode or open the windows to air out the room.</li> </ul>
The air conditioner makes a bubbling sound.	<ul style="list-style-type: none"> <li>• A bubbling sound may be heard when the refrigerant is circulating through the compressor. Let the air conditioner operate in a selected mode.</li> <li>• When you press the <b>Power</b> button on the remote control, noise may be heard from the drain pump inside the air conditioner.</li> </ul>
Water is dripping from the air flow blades.	<ul style="list-style-type: none"> <li>• Check if the air conditioner has been cooling for an extended period of time with the air flow blades pointed downwards. Condensation may generate due to the difference in temperature.</li> </ul>
Remote control is not working.	<ul style="list-style-type: none"> <li>• Check if your batteries are depleted.</li> <li>• Make sure batteries are correctly installed.</li> <li>• Make sure nothing is blocking your remote control sensor.</li> <li>• Check that there are strong lighting apparatus near the air conditioner. Strong light which comes from fluorescent bulbs or neon signs may interrupt the electric waves.</li> </ul>

# Appendix

PROBLEM	SOLUTION
The air conditioner does not turn on or off with the wired remote control.	<ul style="list-style-type: none"><li>• Check if you set the wired remote control for group control.</li></ul>
The wired remote control does not operate.	<ul style="list-style-type: none"><li>• Check if TEST indicator is displayed on the wired remote control. If so, turn off the unit and switch off the circuit breaker. Call your nearest contact center.</li></ul>
The indicators of the digital display flashes.	<ul style="list-style-type: none"><li>• Press the <b>Power</b> button on the remote control to turn the unit off and switch the circuit breaker off. Then, switch it on again.</li></ul>

## OPERATION RANGES

The table below indicates the temperature and humidity ranges the air conditioner can be operated within. Refer to the table for efficient use.

MODE	OPERATIONAL TEMPERATURE		INDOOR HUMIDITY	IF OUT OF CONDITIONS
	INDOOR	OUTDOOR		
COOLING	18 ~ 32°C	-5 ~ 48°C	80% or less	Condensation may occur on the indoor unit with risk to have either water blow off or drops on the floor.
HEATING	27°C or less	-20 ~ 24°C	-	Internal protection triggers and the air conditioner will stop.
DRYING	18 ~ 32°C	-5 ~ 48°C	-	Condensation may occur on the indoor unit with risk to have either water blow off or drops on the floor.



### NOTE

The standardized temperature for heating is 7°C. If the outdoor temperature drops to 0°C or below, the heating capacity can be reduced depending on the temperature condition.

If the cooling operation is used at over 32°C (indoor temperature), it does not cool at its full capacity.

# Instruction for packing and unpacking the unit

## ► Packing the unit as below procedure

1. Put the indoor unit onto the Cushion Base.
2. Assemble Cushion Left and Cushion Right to the both sides of indoor unit.
3. Put the Packing Case from the top of set.
4. Seal the Packing Case.

## ► Unpacking the unit as below procedure

1. Take out the Packing Case from the set.
2. Disassemble Cushion Left and Cushion Right from the both sides of indoor unit.
3. Move the set from the Cushion Base.

## Technical Specifications

MODEL		AM022FNLDEH/TK		AM028FNLDEH/TK	
CLIMATES CLASS		T1	T3	T1	T3
RATED VOLTAGE & FREQUENCY		220 - 240 V~ 50 Hz		220 - 240 V~ 50 Hz	
RATED CURRENT	COOLING	0.30 A	0.30 A	0.32 A	0.32 A
	HEATING (H1)	0.30 A		0.32 A	
RATED POWER INPUT	COOLING	55.00 W	55.00 W	60.00 W	60.00 W
	HEATING (H1)	55.00 W		60.00 W	
EER	COOLING	-	-	-	-
	HEATING (H1)	-		-	
NET WEIGHT		19 kg		19 kg	
DIMENSIONS OF THE UNIT [W×H×D]		700×199×600 mm		700×199×600 mm	
COUNTRY OF ORIGIN		MADE IN CHINA		MADE IN CHINA	

MODEL		AM036FNLDEH/TK		AM045FNLDEH/TK AM045KNLDEH/TK	
CLIMATES CLASS		T1	T3	T1	T3
RATED VOLTAGE & FREQUENCY		220 - 240 V~ 50 Hz		220 - 240 V~ 50 Hz	
RATED CURRENT	COOLING	0.33 A	0.33 A	0.52 A	0.52 A
	HEATING (H1)	0.33 A		0.52 A	
RATED POWER INPUT	COOLING	65.00 W	65.00 W	90.00 W	90.00 W
	HEATING (H1)	65.00 W		90.00 W	
EER	COOLING	-	-	-	-
	HEATING (H1)	-		-	
NET WEIGHT		19.5 kg		24.5 kg / 24.5 kg	
DIMENSIONS OF THE UNIT [W×H×D]		700×199×600 mm		900×199×600 mm	
COUNTRY OF ORIGIN		MADE IN CHINA		MADE IN CHINA	



MODEL		AM056FNLDEH/TK AM056KNLDEH/TK		AM071FNLDEH/TK AM071KNLDEH/TK	
CLIMATES CLASS		T1	T3	T1	T3
RATED VOLTAGE & FREQUENCY		220 - 240 V~ 50 Hz		220 - 240 V~ 50 Hz	
RATED CURRENT	COOLING	0.53 A	0.53 A	0.60 A	0.60 A
	HEATING (H1)	0.53 A		0.60 A	
RATED POWER INPUT	COOLING	95.00 W	95.00 W	120.00 W	120.00 W
	HEATING (H1)	95.00 W		120.00 W	
EER	COOLING	-	-	-	-
	HEATING (H1)	-		-	
NET WEIGHT		24.5 kg / 24.5 kg		30 kg / 30.5 kg	
DIMENSIONS OF THE UNIT [W×H×D]		900×199×600 mm		1100×199×600 mm	
COUNTRY OF ORIGIN		MADE IN CHINA		MADE IN CHINA	

MODEL		AM090FNLDEH/TK AM090KNLDEH/TK		AM112FNLDEH/TK AM112KNLDEH/TK	
CLIMATES CLASS		T1	T3	T1	T3
RATED VOLTAGE & FREQUENCY		220 - 240 V~ 50 Hz		220 - 240 V~ 50 Hz	
RATED CURRENT	COOLING	0.96 A	0.96 A	0.96 A	0.96 A
	HEATING (H1)	0.96 A		0.96 A	
RATED POWER INPUT	COOLING	170.00 W	170.00 W	170.00 W	170.00 W
	HEATING (H1)	170.00 W		170.00 W	
EER	COOLING	-	-	-	-
	HEATING (H1)	-		-	
NET WEIGHT		40 kg / 40.5 kg		40 kg / 40.5 kg	
DIMENSIONS OF THE UNIT [W×H×D]		1300×295×690 mm		1300×295×690 mm	
COUNTRY OF ORIGIN		MADE IN CHINA		MADE IN CHINA	

MODEL		AM128FNLDEH/TK AM128KNLDEH/TK		AM140FNLDEH/TK AM140KNLDEH/TK	
CLIMATES CLASS		T1	T3	T1	T3
RATED VOLTAGE & FREQUENCY		220 - 240 V~ 50 Hz		220 - 240 V~ 50 Hz	
RATED CURRENT	COOLING	1.28 A	1.28 A	1.43 A	1.43 A
	HEATING (H1)	1.28 A		1.43 A	
RATED POWER INPUT	COOLING	200.00 W	200.00 W	220.00 W	220.00 W
	HEATING (H1)	200.00 W		220.00 W	
EER	COOLING	-	-	-	-
	HEATING (H1)	-		-	
NET WEIGHT		41.5 kg / 42 kg		41.5 kg / 42 kg	
DIMENSIONS OF THE UNIT [W×H×D]		1300×295×690 mm		1300×295×690 mm	

# Technical Specifications

COUNTRY OF ORIGIN		MADE IN CHINA		MADE IN CHINA	
MODEL		AM022FNMDEH/TK AM022KNMDEH/TK		AM028FNMDEH/TK AM028KNMDEH/TK	
CLIMATES CLASS		T1	T3	T1	T3
RATED VOLTAGE & FREQUENCY		220 - 240 V~ 50 Hz		220 - 240 V~ 50 Hz	
RATED CURRENT	COOLING	0.40 A	0.40 A	0.40 A	0.40 A
	HEATING (H1)	0.40 A		0.40 A	
RATED POWER INPUT	COOLING	80.00 W	80.00 W	80.00 W	80.00 W
	HEATING (H1)	80.00 W		80.00 W	
EER	COOLING	-	-	-	-
	HEATING (H1)	-		-	
NET WEIGHT		23.5 kg / 24.0 kg		23.5 kg / 24.0 kg	
DIMENSIONS OF THE UNIT [W×H×D]		900×199×600 mm		900×199×600 mm	
COUNTRY OF ORIGIN		MADE IN CHINA		MADE IN CHINA	

MODEL		AM036FNMDEH/TK AM036KNMDEH/TK		AM040FNLPEH/TK	
CLIMATES CLASS		T1	T3	T1	T3
RATED VOLTAGE & FREQUENCY		220 - 240 V~ 50 Hz		220 - 240 V~ 50 Hz	
RATED CURRENT	COOLING	0.55 A	0.55 A	1.85 A	1.85 A
	HEATING (H1)	0.55 A		1.85 A	
RATED POWER INPUT	COOLING	85.00 W	85.00 W	260.00 W	260.00 W
	HEATING (H1)	85.00 W		260.00 W	
EER	COOLING	-	-	-	-
	HEATING (H1)	-		-	
NET WEIGHT		23.5 kg / 24.0 kg		41.5 kg	
DIMENSIONS OF THE UNIT [W×H×D]		900×199×600 mm		1300×295×690 mm	
COUNTRY OF ORIGIN		MADE IN CHINA		MADE IN CHINA	

MODEL		AM056FNLPEH/TK		AM071FNLPEH/TK	
CLIMATES CLASS		T1	T3	T1	T3
RATED VOLTAGE & FREQUENCY		220 - 240 V~ 50 Hz		220 - 240 V~ 50 Hz	
RATED CURRENT	COOLING	1.90 A	1.90 A	1.95 A	1.95 A
	HEATING (H1)	1.90 A		1.95 A	
RATED POWER INPUT	COOLING	270.00 W	270.00 W	280.00 W	280.00 W
	HEATING (H1)	270.00 W		280.00 W	
EER	COOLING	-	-	-	-
	HEATING (H1)	-		-	

NET WEIGHT	41.5 kg	41.5 kg
DIMENSIONS OF THE UNIT [W×H×D]	1300×295×690 mm	1300×295×690 mm
COUNTRY OF ORIGIN	MADE IN CHINA	MADE IN CHINA

MODEL		AM045FNMDEH/TK AM045KNMDEH/TK		AM056FNMDEH/TK AM056KNMDEH/TK	
CLIMATES CLASS		T1	T3	T1	T3
RATED VOLTAGE & FREQUENCY		220 - 240 V~ 50 Hz		220 - 240 V~ 50 Hz	
RATED CURRENT	COOLING	1.15 A	1.15 A	1.10 A	1.10 A
	HEATING (H1)	1.15 A		1.10 A	
RATED POWER INPUT	COOLING	125.00 W	125.00 W	130.00 W	130.00 W
	HEATING (H1)	125.00 W		130.00 W	
EER	COOLING	-	-	-	-
	HEATING (H1)	-		-	
NET WEIGHT		29 kg / 28.5 kg		29 kg / 28.5 kg	
DIMENSIONS OF THE UNIT [W×H×D]		900×260×480 mm		900×260×480 mm	
COUNTRY OF ORIGIN		MADE IN CHINA		MADE IN CHINA	

MODEL		AM071FNMDEH/TK AM071KNMDEH/TK		AM090FNMDEH/TK AM090KNMDEH/TK	
CLIMATES CLASS		T1	T3	T1	T3
RATED VOLTAGE & FREQUENCY		220 - 240 V~ 50 Hz		220 - 240 V~ 50 Hz	
RATED CURRENT	COOLING	1.25 A	1.25 A	1.30 A	1.30 A
	HEATING (H1)	1.25 A		1.30 A	
RATED POWER INPUT	COOLING	190.00 W	190.00 W	240.00 W	240.00 W
	HEATING (H1)	190.00 W		240.00 W	
EER	COOLING	-	-	-	-
	HEATING (H1)	-		-	
NET WEIGHT		29 kg / 28.5 kg		32 kg / 32.5 kg	
DIMENSIONS OF THE UNIT [W×H×D]		900×260×480 mm		1150×260×480 mm	
COUNTRY OF ORIGIN		MADE IN CHINA		MADE IN CHINA	

MODEL		AM112FNMDEH/TK AM112KNMDEH/TK		AM128FNMDEH/TK AM128KNMDEH/TK	
CLIMATES CLASS		T1	T3	T1	T3
RATED VOLTAGE & FREQUENCY		220 - 240 V~ 50 Hz		220 - 240 V~ 50 Hz	
RATED CURRENT	COOLING	1.17 A	1.17 A	1.67 A	1.67 A
	HEATING (H1)	1.17 A		1.67 A	

# Technical Specifications

RATED POWER INPUT	COOLING	260.00 W	260.00 W	370.00 W	370.00 W
	HEATING (H1)	260.00 W		370.00 W	
EER	COOLING	-	-	-	-
	HEATING (H1)	-		-	
NET WEIGHT		36.5 kg / 36.0 kg		48.5 kg / 48.5 kg	
DIMENSIONS OF THE UNIT [W×H×D]		1150×320×480 mm		1200×360×650 mm	
COUNTRY OF ORIGIN		MADE IN CHINA		MADE IN CHINA	

MODEL		AM140FNMDEH/TK AM140KNMDEH/TK		AM112FNHDEH/TK	
CLIMATES CLASS		T1	T3	T1	T3
RATED VOLTAGE & FREQUENCY		220 - 240 V~ 50 Hz		220 - 240 V~ 50 Hz	
RATED CURRENT	COOLING	1.86 A	1.86 A	2.35 A	2.35 A
	HEATING (H1)	1.86 A		2.35 A	
RATED POWER INPUT	COOLING	410.00 W	410.00 W	305.00 W	305.00 W
	HEATING (H1)	410.00 W		305.00 W	
EER	COOLING	-	-	-	-
	HEATING (H1)	-		-	
NET WEIGHT		48.5 kg / 48.5 kg		57 kg	
DIMENSIONS OF THE UNIT [W×H×D]		1200×360×650 mm		1200×360×650 mm	
COUNTRY OF ORIGIN		MADE IN CHINA		MADE IN CHINA	

MODEL		AM128FNHDEH/TK		AM140FNHDEH/TK	
CLIMATES CLASS		T1	T3	T1	T3
RATED VOLTAGE & FREQUENCY		220 - 240 V~ 50 Hz		220 - 240 V~ 50 Hz	
RATED CURRENT	COOLING	2.58 A	2.58 A	3.00 A	3.00 A
	HEATING (H1)	2.58 A		3.00 A	
RATED POWER INPUT	COOLING	333.00 W	333.00 W	385.00 W	385.00 W
	HEATING (H1)	333.00 W		385.00 W	
EER	COOLING	-	-	-	-
	HEATING (H1)	-		-	
NET WEIGHT		57 kg		57 kg	
DIMENSIONS OF THE UNIT [W×H×D]		1200×360×650 mm		1200×360×650 mm	
COUNTRY OF ORIGIN		MADE IN CHINA		MADE IN CHINA	

MODEL		AM160KNMDEH/TK AM160KNMDEH1TK		AM022KNLDEH/TK	
CLIMATES CLASS		T1	T3	T1	T3
RATED VOLTAGE & FREQUENCY		220 - 240 V~ 50 Hz		220 - 240 V~ 50 Hz	

RATED CURRENT	COOLING	2.24 A	2.24 A	0.25 A	0.25 A
	HEATING (H1)	2.24 A		0.25 A	
RATED POWER INPUT	COOLING	485.00 W	485.00 W	30.00 W	30.00 W
	HEATING (H1)	485.00 W		30.00 W	
EER	COOLING	-	-	-	-
	HEATING (H1)	-		-	
NET WEIGHT		57 kg / 50.5 kg		15.3 kg	
DIMENSIONS OF THE UNIT [W×H×D]		1200×360×650 mm		700×199×440 mm	
COUNTRY OF ORIGIN		MADE IN CHINA		MADE IN CHINA	

MODEL		AM028KNLDEH/TK		AM036KNLDEH/TK	
CLIMATES CLASS		T1	T3	T1	T3
RATED VOLTAGE & FREQUENCY		220 - 240 V~ 50 Hz		220 - 240 V~ 50 Hz	
RATED CURRENT	COOLING	0.28 A	0.28 A	0.33 A	0.33 A
	HEATING (H1)	0.30 A		0.35 A	
RATED POWER INPUT	COOLING	34.00 W	34.00 W	40.00 W	40.00 W
	HEATING (H1)	36.00 W		42.00 W	
EER	COOLING	-	-	-	-
	HEATING (H1)	-		-	
NET WEIGHT		15.3 kg		15.7 kg	
DIMENSIONS OF THE UNIT [W×H×D]		700×199×440 mm		700×199×440 mm	
COUNTRY OF ORIGIN		MADE IN CHINA		MADE IN CHINA	

# SAMSUNG

QUESTIONS OR COMMENTS?

COUNTRY	CALL	OR VISIT US ONLINE AT
U.A.E	800-SAMSUNG (800 - 726 7864)	<a href="http://www.samsung.com/ae/support">www.samsung.com/ae/support</a> (English) <a href="http://www.samsung.com/ae_ar/support">www.samsung.com/ae_ar/support</a> (Arabic)
OMAN	800-SAMSUNG (800 - 726 7864)	
KUWAIT	183-CALL (183-2255)	
BAHRAIN	8000-GSAM (8000-4726)	
QATAR	800-CALL (800-2255)	
EGYPT	08000-7267864 16580	<a href="http://www.samsung.com/eg/support">www.samsung.com/eg/support</a>
ALGERIA	3004	<a href="http://www.samsung.com/n_africa/support">www.samsung.com/n_africa/support</a>
PAKISTAN	0800-Samsung (72678)	<a href="http://www.samsung.com/pk/support">www.samsung.com/pk/support</a>
TUNISIA	80 1000 12	<a href="http://www.samsung.com/n_africa/support">www.samsung.com/n_africa/support</a>
JORDAN	0800-22273 06 5777444	<a href="http://www.samsung.com/levant">www.samsung.com/levant</a>
SYRIA	962 5777444	
IRAN	021-8255 [CE] 021-42132 [HHP]	<a href="http://www.samsung.com/iran/support">www.samsung.com/iran/support</a>
MOROCCO	080 100 22 55	<a href="http://www.samsung.com/n_africa/support">www.samsung.com/n_africa/support</a>
SAUDI ARABIA	800 247 3457 (800 24/7 HELP)	<a href="http://www.samsung.com/sa/home">www.samsung.com/sa/home</a> <a href="http://www.samsung.com/sa_en">www.samsung.com/sa_en</a>
TURKEY	444 77 11	<a href="http://www.samsung.com/tr/support">www.samsung.com/tr/support</a>
RUSSIA	8-800-555-55-55 (VIP care 8-800-555-55-88)	<a href="http://www.samsung.com/ru/support">www.samsung.com/ru/support</a>
GEORGIA	0-800-555-555	<a href="http://www.samsung.com/support">www.samsung.com/support</a>
ARMENIA	0-800-05-555	<a href="http://www.samsung.com/support">www.samsung.com/support</a>
AZERBAIJAN	0-88-555-55-55	<a href="http://www.samsung.com/support">www.samsung.com/support</a>
KAZAKHSTAN	8-10-800-500-55-500 (GSM: 7799, VIP care 7700)	<a href="http://www.samsung.com/kz_ru/support">www.samsung.com/kz_ru/support</a>
UZBEKISTAN	00-800-500-55-500 (GSM: 7799)	<a href="http://www.samsung.com/support">www.samsung.com/support</a>
KYRGYZSTAN	00-800-500-55-500 (GSM: 9977)	<a href="http://www.samsung.com/support">www.samsung.com/support</a>
TAJIKISTAN	8-10-800-500-55-500	<a href="http://www.samsung.com/support">www.samsung.com/support</a>
MONGOLIA	+7-495-363-17-00	<a href="http://www.samsung.com/support">www.samsung.com/support</a>
UKRAINE	0-800-502-000	<a href="http://www.samsung.com/ua/support">www.samsung.com/ua/support</a> (Ukrainian) <a href="http://www.samsung.com/ua_ru/support">www.samsung.com/ua_ru/support</a> (Russian)
BELARUS	810-800-500-55-500	<a href="http://www.samsung.com/support">www.samsung.com/support</a>
MOLDOVA	0-800-614-40	<a href="http://www.samsung.com/support">www.samsung.com/support</a>
INDONESIA	021-56997777 08001128888	<a href="http://www.samsung.com/id/support">www.samsung.com/id/support</a>